Soptember 29, 1970







HRALEH AND CAPETY PROCEDURE FOR HANDLING HICKEL 63 PLATING SOLIFIONS AND PARTS

As a follow-up of our convergation, the following is required in view of the radiosetive nature of this material:

A. Personnel Clearence

- Personnel shall be approved by Medical regarding physical status prior to handling this unterial.
- 2. Personnel shall be given an orientation by Health and Safety prior to handling this material.

B. Parsonnel Protection

- Personnal shall wear protective clothing and equipment normally required for hendling acid plating solutions (are protection, gloves, and plastic apron).
- 2. Personnel shall wash their hands and any other skin areas upon contact and upon termination of work.
- Personnel shall not ent, drink, or make while handling this unterial, and shall wash their hands prior to enting, drinking, or smoking.

C. Material Handling

- All stock and plating solutions shall be labeled with rediction warning tape.
- 2. Completed parts shall be placed in plastic begs and labeled with radiation warning tape.
- When parts are to be removed from the plating tenha, the solution shall be allowed to drain to eliminate unnecessary transfer of material to the rinse tenk and possible spillage between tenha.
- 4. Any spilings of material shall be cleaned up immediately. Health and Safety shall be contacted to monitor the area after clean up.

Euphumber 29, 1970

Pege 2

- All Makente and any Kim Wiyes used shall be placed in plastic bags, scaled, and inheled with rediction varying tape.
- All equipment in content with the plating solution shall be thoroughly cleaned upon termination of the project and monitored by Health and Bafety prior to being used for other projects.

D. Disposal of Wastes

- All waste stock and plating solutions shall be placed in plastic containers, labeled with rediction warning tape, and sent to department 20 D for disposal.
- All other generated waste (C.5), shall be also sent to department 20 D for disposal.

Please contact the writer at extensions cor or regarding any questions.

Your cooperation in this matter will be most appreciated.

